

Removing the Plastic Protector on the Mike Microphone's Connector

Service Note

Export Date: 11/07/2025

Exported by: Emilie Mesureur


Table of Contents

1. Introduction	4
2. Removing the Plastic Protector.....	5
3. Replacing the Plastic Protector	6
4. Video	7

Version	1.00
Creation date	2025/11/07
Author	EM
Type	Service note
Range of product	Mike "Push&Lock" Microphones
Products	Mike LPM, PLM 301F, PLM401F, PLM502F, PLM602F, PLM402F, PLM40FF, PLM18FF
	televic

1. Introduction

The connector of the Mike "Push&Lock" microphone is covered with a removable plastic protector that keeps the microphone in place in the packaging during transport and storage, hence protecting the windshield in the box.




The following note explains how to remove and replace the plastic protector.

2. Removing the Plastic Protector

1. To remove the plastic protector around the connector, press the unlock button of the microphone.



2. Gently pull the protector away from the microphone.



3. Replacing the Plastic Protector

1. Slide the plastic protector with the flat part upwards around the microphone's connector.



i In case the microphones need to be stored and transported again in the packaging boxes, keep the protectors and replace them on the connectors when needed. If not, you can throw away the protectors.

4. Video

Watch the video below for a detailed view on how to remove and replace the plastic protector:

<https://documents.televic.digital/conference/index.php/s/4JXsT2nsfQdAxYS>



HQ Belgium

+32 51 30 30 45

conference@televic.com

www.televic.com/en/conference

Asia

+86 21 61 48 01 23

conference@televic.co

www.televic-conference.com.cn

France

+33 3 74 09 52 76

conference-france@televic.com

www.televic-conference.fr

United States

+1 916 920 0901

conference-us@televic.com

*All information
copyright Televic
Conference, 2025.
Televic reserves the
right to change this
document without
notice.*